

Sprint Mobile Hotspot Information

Two Sprint Mobile Hotspots are available to borrow from Jenkins for a two week loan period. Each box contains one battery-powered Sprint Mobile Hotspot R850 and a micro-USB charger. Instructions, WiFi network names, and passwords are printed on the box. To recharge the battery, simply insert the small end of the micro-USB cable into the charging port on the Hotspot, and plug the adapter into a standard power outlet. You can connect to the WiFi network when the Hotspot is charging, or when it is unplugged and running on battery power, as long as it is on and within a network coverage zone.

To turn the Hotspot on or off, press and hold the Power Button on the front for at least two seconds. A “Welcome” or “Goodbye” screen will appear briefly. The device is on if the blue light is flashing. Open the WiFi application or controls on the computer, tablet, or cell phone, and use the provided network name and password to connect with the Hotspot. You can also cycle through a series of screens on the Hotspot to view device information, including the signal strength, battery status, WiFi name, and WiFi password.

Note: *Use of the Sprint Mobile Hotspot and wireless access network is entirely at the risk of the user. Jenkins Law Library assumes no responsibility for the safety of equipment or device configurations, security, or data files resulting from connection to the wireless access network or the Internet, or liability for any consequent damage to hardware, software or data. Signal strength may vary. Staff are not trained to configure or troubleshoot wireless electronic devices. If there is a problem with the device, please return to Jenkins Law Library.*

